




r



r r

字符	空	-	0	1	2	3	4	5	6	7	8	9
字型	8	8	8	8	8	8	8	8	8	8	8	8
字符	A	B	C	D	E	F	G	H	I	J	K	L
字型	8	8	8	8	8	8	8	8	8	8	8	8

显示代码表															
代码	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14
显示	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14
代码	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
29	显示	15	16	17	18	19	20	21	22	23	24	25	26	27	28
44	代码	30	31	32	33	34	35	36	37	38	39	40	41	42	43
44	显示	30	31	32	33	34	35	36	37	38	39	40	41	42	43
59	代码	45	46	47	48	49	50	51	52	53	54	55	56	57	58
	显示	45	46	47	48	49	50	51	52	53	54	55	56	57	58
B	G	M	M1	M2	M3	显示	B1	B2	B3	B4	B5	B6	B7	B8	B9
84	85	86	87	88	89	代码	75	76	77	78	79	80	81	82	83
H	H1	H2	H3	3A	12A	显示	P	P1	P2	P3	R	R1	R2	R3	L
99	100	101	102	103	104	代码	90	91	92	93	94	95	96	97	98
	C1	C2	C3	C4	C	显示	12B	13A	17A	17B	5A	G1	G2	G3	F
114	115	116	117	118	119	代码	105	106	107	108	109	110	111	112	113
5F	1C	2C	3C	4C		显示	D1	D2	D3	D4	D	1F	2F	3F	4F
129	130	131	132	133	134	代码	120	121	122	123	124	125	126	127	128
E	A	UB	LG	UG	6A	显示	1B	2B	3B	4B	1A	2A	4A	CF	LB
144	145	146	147	148	149	代码	135	136	137	138	139	140	141	142	143
15A	13B	K	U	S	EG	显示	6B	7A	7B	5B	6C				SB
159	160	161	162	163	164	代码	150	151	152	153	154	155	156	157	158
	GF	MZ	SR	19A	Z	显示	KG								
174	175	176	177	178	179	代码	165	166	167	168	169	170	171	172	173
AG	BE	RF	1L	5L	1M	显示	HP	AB	PH	AA	L1	L2	L3	PB	
88	189	190	191	192	193	194	代码	180	181	182	183	184	185	186	187
4B	AS	15B	16A	16B	22A	22B	显示	3M	4M	B1A	B2A	B3A	B4A	PM	14A
03	204	205	206	207	208	209	代码	195	196	197	198	199	200	201	202
0	51	52	53	54	55	56	显示	E1	E2	S1	S2	S3	E3	E4	49
18	219	220	221	222	223	224	代码	210	211	212	213	214	215	216	217
4	P5	LD	JC	S4	S5	SS	显示	57	58	59	60	61	62	63	64
33	234	235	236	237	238	239	代码	225	226	227	228	229	230	231	232
8	LP	1P	MR	PC	P6	P7	显示	LL	5C	9F	LF	UF	EF	33A	S6
24							代码	240	241	242	243	244	245	246	
AE							显示	P8	P9		P3A	P7A	P8A	P9A	
