



Figure 1 Bluetooth module sjt-uartbt-v4

## Android system connection method




Figure 2 Main interface




Figure 3 Connection interface




Figure 4 Connection succeeded

## IOS system connection method




Figure 5 Turn on Bluetooth




Figure 6 Enter the link




Figure 7 Select device